KIT SINFONIA SYSTEM
UP TO 6-LIGHT COMPOSITION
rev:0



- CA103DWHEZZ
- CA103DBBEZZ
- CA103DCHEZZ
- CA103DHGEZZ



- CA106RWHEZZ
- CA106RBBEZZ
- CA106RCHEZZ
- CA106RHGEZZ

■ KIT0110



■ KIT0106

KIT NOT INCLUDED



CA107DWHWDI - 3000K	CA108DWHWDI - 3000K	CA109DWHWDI- 3000K	CA110DWHWDI- 3000K
CA107DBBWDI - 3000K	CA108DBBWDI - 3000K	CA109DBBWDI- 3000K	CA110DBBWDI- 3000K
CA107DCHWDI - 3000K	CA108DCHWDI - 3000K	CA109DCHWDI- 3000K	CA110DCHWDI- 3000K
CA107DHGWDI - 3000K	CA108DHGWDI - 3000K	CA109DHGWDI- 3000K	CA110DHGWDI- 3000K
CA107DWHMDI- 2700K	CA108DWHMDI- 2700K	CA109DWHMDI- 2700K	CA110DWHMDI- 2700K
CA107DBBMDI- 2700K	CA108DBBMDI- 2700K	CA109DBBMDI- 2700K	CA110DBBMDI- 2700K
CA107DCHMDI - 2700K	CA108DCHMDI - 2700K	CA109DCHMDI- 2700K	CA110DCHMDI- 2700K
CA107DHGMDI - 2700K	CA108DHGMDI - 2700K	CA109DHGMDI- 2700K	CA110DHGMDI- 2700K
4W	4W	6W	6W

KIT NOT INCLUDED



CA113DWHWDI - 3000K	CA112DWHWDI - 3000K	CA111DWHWDI - 3000K
CA113DBBWDI - 3000K	CA112DBBWDI - 3000K	CA111DBBWDI - 3000K
CA113DCHWDI - 3000K	CA112DCHWDI - 3000K	CA111DCHWDI - 3000K
CA113DHGWDI - 3000K	CA112DHGWDI - 3000K	CA111DHGWDI - 3000K
CA113DWHMDI- 2700K	CA112DWHMDI- 2700K	CA111DWHMDI- 2700K
CA113DBBMDI- 2700K	CA112DBBMDI- 2700K	CA111DBBMDI- 2700K
CA113DCHMDI - 2700K	CA112DCHMDI - 2700K	CA111DCHMDI - 2700K
CA113DHGMDI - 2700K	CA112DHGMDI - 2700K	CA111DHGMDI - 2700K
6W	6W	6W

KIT NOT INCLUDED









KIT SINFONIA SYSTEM
UP TO 6-LIGHT COMPOSITION
rev:0

1



2



3



4



5



6





DETTAGLIO A

7



8



KIT SINFONIA SYSTEM
UP TO 6-LIGHT COMPOSITION
rev:0





MIN 2.5 - MAX 36W

ON/OFF



KIT SINFONIA SYSTEM
UP TO 6-LIGHT COMPOSITION
rev:0



MIN 2.5 - MAX 36W



ON/OFF



KIT SINFONIA SYSTEM
UP TO 6-LIGHT COMPOSITION
rev:0



MIN 2.5 - MAX 36W



KIT0110







ISTRUZIONI PER IL LAVAGGIO DELL'APPARECCHIO D'ILLUMINAZIONE
LUMINAIRE CARE INSTRUCTIONS
ISTRUCCIONES PARA LIMPIAR LA LUMINARA
INSTRUCTIONS POUR LE LAVAGE DE L'APPAREIL D'ECLAIRAGE
ANLEITUNG ZUR REINIGUNG DES BELEUCHTUNGSGERATS







IT - ATTENZIONE!!!

Lavare la superficie del diffusore luce con panno umido, utilizzando solo acqua e sapone neutro.

EN - WARNING!!!

Wipe clean with a cloth damped in water with neutral detergent.

ES - ATENCION!!!

Limpie la superficie del difusor con un pano humedecido con agua y jabon neutro.

FR - ATTENTION!!!

Laver la surface du diffuseur de lumiere a l'aide d'un chiffon humide et en utlisant seulement de l'eau et du savon neutre.

DE - ACHTUNG!!!

Die oberflache vom lampenschirm mit einem feuchten lappen reinigen. De lappen mit wasser und neutralseife befeuchten.





IT - ATTENZIONE!!!

Non utilizzare panni abrasivi e/o solventi.

EN - WARNING!!!

Avoiding the use of chemical solvents and/or abrasive cloths.

ES - ATENCION!!!

No utilizar panos abrasivos y solventes.

FR - ATTENTION!!!

Ne pas utiliser de chiffons abrasifs ou de dissolvants.

DE - ACHTUNG!!!

Abschleifende tuche und/oder losungmittel nicht benutzen.

KIT SINFONIA SYSTEM
UP TO 24-LIGHT COMPOSITION
rev:0



- ☐ CA105DWHEZZ
- ■ CA105DBBEZZ
- ■ CA105DCHEZZ
- ■ CA105DHGEZZ



■ KIT0110



■ KIT0106

- ☐ CA106RWHEZZ
- ■ CA106RBBEZZ
- ■ CA106RCHEZZ
- ■ CA106RHGEZZ

KIT NOT INCLUDED



CA107DWHWDI - 3000K	CA108DWHWDI - 3000K	CA109DWHWDI- 3000K	CA110DWHWDI- 3000K
CA107DBBWDI - 3000K	CA108DBBWDI - 3000K	CA109DBBWDI- 3000K	CA110DBBWDI- 3000K
CA107DCHWDI - 3000K	CA108DCHWDI - 3000K	CA109DCHWDI- 3000K	CA110DCHWDI- 3000K
CA107DHGWDI - 3000K	CA108DHGWDI - 3000K	CA109DHGWDI- 3000K	CA110DHGWDI- 3000K
CA107DWHMDI- 2700K	CA108DWHMDI- 2700K	CA109DWHMDI- 2700K	CA110DWHMDI- 2700K
CA107DBBMDI- 2700K	CA108DBBMDI- 2700K	CA109DBBMDI- 2700K	CA110DBBMDI- 2700K
CA107DCHMDI - 2700K	CA108DCHMDI - 2700K	CA109DCHMDI- 2700K	CA110DCHMDI- 2700K
CA107DHGMDI - 2700K	CA108DHGMDI - 2700K	CA109DHGMDI- 2700K	CA110DHGMDI- 2700K
4W	4W	6W	6W

KIT NOT INCLUDED



CA113DWHWDI - 3000K	CA112DWHWDI - 3000K	CA111DWHWDI - 3000K
CA113DBBWDI - 3000K	CA112DBBWDI - 3000K	CA111DBBWDI - 3000K
CA113DCHWDI - 3000K	CA112DCHWDI - 3000K	CA111DCHWDI - 3000K
CA113DHGWDI - 3000K	CA112DHGWDI - 3000K	CA111DHGWDI - 3000K
CA113DWHMDI- 2700K	CA112DWHMDI- 2700K	CA111DWHMDI- 2700K
CA113DBBMDI- 2700K	CA112DBBMDI- 2700K	CA111DBBMDI- 2700K
CA113DCHMDI - 2700K	CA112DCHMDI - 2700K	CA111DCHMDI - 2700K
CA113DHGMDI - 2700K	CA112DHGMDI - 2700K	CA111DHGMDI - 2700K
6W	6W	6W

KIT NOT INCLUDED













KIT SINFONIA SYSTEM
UP TO 24-LIGHT COMPOSITION
rev:0

linealight
COLLECTION

1



2



3



4



KIT SINFONIA SYSTEM
UP TO 24-LIGHT COMPOSITION
rev:0

5



6



1



2



3



4



DETTAGLIO A

7



8



KIT SINFONIA SYSTEM
UP TO 24-LIGHT COMPOSITION
rev:0





ON/OFF



KIT SINFONIA SYSTEM
UP TO 24-LIGHT COMPOSITION
rev:0





ON/OFF



KIT SINFONIA SYSTEM
UP TO 24-LIGHT COMPOSITION
rev:0



MIN 24 - MAX 75W

KIT0110



ISTRUZIONI PER IL LAVAGGIO DELL'APPARECCHIO D'ILLUMINAZIONE
LUMINAIRE CARE INSTRUCTIONS
ISTRUCCIONES PARA LIMPIAR LA LUMINARA
INSTRUCTIONS POUR LE LAVAGE DE L'APPAREIL D'ECLAIRAGE
ANLEITUNG ZUR REINIGUNG DES BELEUCHTUNGSGERATS







IT - ATTENZIONE!!!

Lavare la superficie del diffusore luce con panno umido, utilizzando solo acqua e sapone neutro.

EN - WARNING!!!

Wipe clean with a cloth damped in water with neutral detergent.

ES - ATENCION!!!

Limpie la superficie del difusor con un pano humedecido con agua y jabon neutro.

FR - ATTENTION!!!

Laver la surface du diffuseur de lumiere a l'aide d'un chiffon humide et en utlisant seulement de l'eau et du savon neutre.

DE - ACHTUNG!!!

Die oberflache vom lampenschirm mit einem feuchten lappen reinigen. De lappen mit wasser und neutralseife befeuchten.





IT - ATTENZIONE!!!

Non utilizzare panni abrasivi e/o solventi.

EN - WARNING!!!

Avoiding the use of chemical solvents and/or abrasive cloths.

ES - ATENCION!!!

No utilizar panos abrasivos y solventes.

FR - ATTENTION!!!

Ne pas utiliser de chiffons abrasifs ou de dissolvants.

DE - ACHTUNG!!!

Abschleifende tuche und/oder losungmittel nicht benutzen.

KIT SINFONIA SYSTEM
UP TO 12-LIGHT COMPOSITION
rev:0



- CA104DWHEZZ
- CA104DBBEZZ
- CA104DCHEZZ
- CA104DHGEZZ



- CA106RWHEZZ
- CA106RBBEZZ
- CA106RCHEZZ
- CA106RHGEZZ

KIT0110

KIT0106

KIT NOT INCLUDED



CA107DWHWDI - 3000K	CA108DWHWDI - 3000K	CA109DWHWDI- 3000K	CA110DWHWDI- 3000K
CA107DBBWDI - 3000K	CA108DBBWDI - 3000K	CA109DBBWDI- 3000K	CA110DBBWDI- 3000K
CA107DCHWDI - 3000K	CA108DCHWDI - 3000K	CA109DCHWDI- 3000K	CA110DCHWDI- 3000K
CA107DHGWDI - 3000K	CA108DHGWDI - 3000K	CA109DHGWDI- 3000K	CA110DHGWDI- 3000K
CA107DWHMDI- 2700K	CA108DWHMDI- 2700K	CA109DWHMDI- 2700K	CA110DWHMDI- 2700K
CA107DBBMDI- 2700K	CA108DBBMDI- 2700K	CA109DBBMDI- 2700K	CA110DBBMDI- 2700K
CA107DCHMDI - 2700K	CA108DCHMDI - 2700K	CA109DCHMDI- 2700K	CA110DCHMDI- 2700K
CA107DHGMDI - 2700K	CA108DHGMDI - 2700K	CA109DHGMDI- 2700K	CA110DHGMDI- 2700K
4W	4W	6W	6W

KIT NOT INCLUDED



CA113DWHWDI - 3000K	CA112DWHWDI - 3000K	CA111DWHWDI - 3000K
CA113DBBWDI - 3000K	CA112DBBWDI - 3000K	CA111DBBWDI - 3000K
CA113DCHWDI - 3000K	CA112DCHWDI - 3000K	CA111DCHWDI - 3000K
CA113DHGWDI - 3000K	CA112DHGWDI - 3000K	CA111DHGWDI - 3000K
CA113DWHMDI- 2700K	CA112DWHMDI- 2700K	CA111DWHMDI- 2700K
CA113DBBMDI- 2700K	CA112DBBMDI- 2700K	CA111DBBMDI- 2700K
CA113DCHMDI - 2700K	CA112DCHMDI - 2700K	CA111DCHMDI - 2700K
CA113DHGMDI - 2700K	CA112DHGMDI - 2700K	CA111DHGMDI - 2700K
6W	6W	6W

KIT NOT INCLUDED













KIT SINFONIA SYSTEM
UP TO 12-LIGHT COMPOSITION
rev:0

1



2



3



4



5



6





7



8



KIT SINFONIA SYSTEM
UP TO 12-LIGHT COMPOSITION
rev:0





MIN 24 - MAX 75W

ON/OFF



KIT SINFONIA SYSTEM
UP TO 12-LIGHT COMPOSITION
rev:0





MIN 24 - MAX 75W

ON/OFF



KIT SINFONIA SYSTEM
UP TO 12-LIGHT COMPOSITION
rev:0



MIN 24 - MAX 75W

KIT0110







ISTRUZIONI PER IL LAVAGGIO DELL'APPARECCHIO D'ILLUMINAZIONE
LUMINAIRE CARE INSTRUCTIONS
ISTRUCCIONES PARA LIMPIAR LA LUMINARA
INSTRUCTIONS POUR LE LAVAGE DE L'APPAREIL D'ECLAIRAGE
ANLEITUNG ZUR REINIGUNG DES BELEUCHTUNGSGERATS







IT - ATTENZIONE!!!

Lavare la superficie del diffusore luce con panno umido, utilizzando solo acqua e sapone neutro.

EN - WARNING!!!

Wipe clean with a cloth damped in water with neutral detergent.

ES - ATENCION!!!

Limpie la superficie del difusor con un pano humedecido con agua y jabon neutro.

FR - ATTENTION!!!

Laver la surface du diffuseur de lumiere a l'aide d'un chiffon humide et en utlisant seulement de l'eau et du savon neutre.

DE - ACHTUNG!!!

Die oberflache vom lampenschirm mit einem feuchten lappen reinigen. De lappen mit wasser und neutralseife befeuchten.





IT - ATTENZIONE!!!

Non utilizzare panni abrasivi e/o solventi.

EN - WARNING!!!

Avoiding the use of chemical solvents and/or abrasive cloths.

ES - ATENCION!!!

No utilizar panos abrasivos y solventes.

FR - ATTENTION!!!

Ne pas utiliser de chiffons abrasifs ou de dissolvants.

DE - ACHTUNG!!!

Abschleifende tuche und/oder losungmittel nicht benutzen.